



THE CHRYSLER

## PACIFICA 2017 QUICK REFERENCE GUIDE



## SPEED CONTROL

### Adaptive Cruise Control (ACC) – If Equipped

If your vehicle is equipped with Adaptive Cruise Control, the controls operate exactly the same as the standard cruise control, with one difference. You can set a specified distance you would like to maintain between you and the vehicle in front of you.

- If the ACC sensor detects a vehicle ahead, ACC will apply limited braking or acceleration automatically to maintain a preset following distance while matching the speed of the vehicle ahead.

#### NOTE:

Your vehicle will not exceed the cruise speed you have set.

- If the sensor does not detect a vehicle directly ahead of you, it functions like a standard cruise control system, maintaining the speed you set.



Adaptive Cruise Switches

- 1 – Adaptive Cruise Control (ACC) On/Off
- 2 – Distance Setting – Decrease
- 3 – Distance Setting – Increase

For further information and applicable warnings and cautions, please refer to your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

## SAFETY FEATURES

### Forward Collision Warning With Mitigation – If Equipped

The Forward Collision Warning (FCW) system provides the driver with active braking, audible and visual warnings (within the instrument cluster display) and may apply a brake jerk to warn the driver when it detects a potential frontal collision. The warnings and limited braking are intended to provide the driver with enough time to react and avoid or mitigate the potential collision.

FCW monitors the information from the forward-looking sensor, as well as the Electronic Brake Controller (EBC) and wheel speed sensors, to calculate the probability of a collision. When the system determines that a collision is probable, a warning message (both audible and visual) will be displayed within the cluster display along with a brake jerk warning (previously enabled in the Uconnect Settings). When the system senses the driver applying the brakes to avoid a probable collision, additional brake force will be provided to the vehicle. When the system determines a collision with the vehicle in front of you is no longer probable, the warning message will be deactivated.

## PARKSENSE

### NOTE:

The FCW feature can be customized and turned off through the Uconnect System touchscreen.

For further information and applicable warnings and cautions, please refer to your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

### LaneSense — If Equipped

The LaneSense system is operational at speeds above 37 mph (60 km/h) and below 112 mph (180 km/h). The LaneSense system uses a forward looking camera to detect lane markings and measure vehicle position within the lane boundaries.

#### Turning LaneSense ON Or OFF

The default status of LaneSense is "OFF". The LaneSense button is located on the switch panel below the Uconnect display.

#### LaneSense Warning Message

The LaneSense system will indicate the current lane drift condition through the instrument cluster display. The instrument cluster display will provide a visual warning depicting the unintentional lane departure.

When both lane markings are detected and the driver unintentionally drifts out of the lane (no turn signal applied), the LaneSense system provides a haptic warning in the form of torque applied to the steering wheel to prompt the driver to remain within the lane boundaries. The driver may manually override the haptic warning by applying torque into the steering wheel at any time. When only a single lane marking is detected and the driver unintentionally drifts across the lane marking (no turn signal applied), the LaneSense system provides a visual warning through the instrument cluster display to prompt the driver to remain within the lane. When only a single lane marking is detected, a haptic (torque) warning will not be provided.

### NOTE:

The LaneSense system can be customized and turned off through the Uconnect System touchscreen.

For further information and applicable warnings and cautions, please refer to your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

### ParkSense Rear Or ParkSense Front And Rear Park Assist — If Equipped

- The four ParkSense sensors, located in the rear fascia/bumper, monitor the area behind the vehicle that is within the sensor's field of view.
- The six ParkSense sensors, located in the front fascia/bumper, monitor the area in front of the vehicle that is within the sensors' field of view.
- The sensors can detect obstacles from approximately 12 inches (30 cm) up to 79 inches (200 cm) from the rear bumper while the vehicle is in REVERSE, a warning will display in the instrument cluster and a chime will sound (when Sound and Display is selected from the Customer Programmable Features section of the Uconnect System screen). As the vehicle moves closer to the object, the chime rate will change from single 1/2 second tone, to slow, to fast, to continuous.
- If the system detects a potential impact with an object, the vehicle brakes may be applied.

For further information and applicable warnings and cautions, please refer to your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

## PARKVIEW

### Rear Back-Up Camera — If Equipped

Your vehicle may be equipped with the ParkView Rear Back-Up Camera that allows you to see an on-screen image of the rear surroundings of your vehicle whenever the gear selector is put into REVERSE. The ParkView Rear Back-Up Camera image will be displayed on the Uconnect Display, located on the center stack of the instrument panel. The ParkView Rear Back-Up Camera is located on the rear of the vehicle above the rear license plate.

For further information and applicable warnings and cautions, please refer to your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

### Surround View Camera System — If Equipped

Your vehicle may be equipped with the Surround View Camera System that allows you to see an on-screen image of the surroundings and top view of your vehicle whenever the gear selector is put into REVERSE or a different view is selected through the "on screen soft buttons". The top view of the vehicle will show

which doors are open. The image will be displayed on the touchscreen display along with a caution note "Check Entire Surroundings" across the top of the screen. After five seconds, this note will disappear. The Surround View Camera System is comprised of four sequential cameras located in the front grille, rear liftgate and side mirrors.

#### NOTE:

The Surround View Camera System has programmable settings that may be selected through the Uconnect System.

When the vehicle is shifted out of REVERSE (with camera delay turned ON), the camera image will continue to be displayed for up to 10 seconds after shifting out of REVERSE, unless the vehicle speed exceeds 8 mph (13 km/h) or the vehicle is shifted into PARK or the ignition is switched to the OFF position.

When the vehicle is shifted out of REVERSE (with camera delay turned OFF), the surround view camera mode is exited and the last known screen appears again. There is a touch screen button (X) to disable the display of the camera image.

### Modes of Operation

Additional camera modes can be selected when the vehicle is in any gear and the surround view camera system is activated by pressing the soft key located in the "Controls" screen or the "Apps" screen in the Uconnect system.

### Deactivation

The system can be deactivated in the following conditions:

- The speed of the vehicle reaches greater than 8 mph (13 km/h).
- The vehicle is out of REVERSE for greater than 10 seconds.
- The vehicle shifted into PARK.
- If the vehicle is in any gear other than REVERSE, press the "X" button.

For further information and applicable warnings and cautions, please refer to your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

# SEATS

## Memory Seats — If Equipped

This feature allows the driver to store up to two different memory profiles for easy recall through a memory switch. Your vehicle is equipped with two key fobs, one key fob can be linked to memory position 1 and the other can be linked to memory position 2.

The memory positions can also be programmed to recall the same positions when the unlock button is pushed.



Memory Seat Buttons

### To Create A New Memory Profile

1. Cycle the vehicle's ignition to the ON/RUN position (Do not start the engine).
2. Adjust all memory profile settings to desired preferences (i.e., seat, side mirror, power tilt and telescopic steering column [if equipped], and radio station presets).
3. Push and release the S (Set) button on the memory switch.
4. Within five seconds, push and release either of the memory buttons (1) or (2). The instrument cluster display will show which memory position has been set.

### NOTE:

Memory profiles can be set without the vehicle in PARK, but the vehicle must be in PARK to recall a memory profile.

For further information and applicable warnings and cautions, please refer to your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

## Stow 'N Go Seating — If Equipped

On vehicles equipped with Stow 'n Go seating, the second and third row seats can be folded into the floor for convenient storage.

### Stow 'N Go Assist — If Equipped

With the Stow 'n Go Assist feature, the front seat will move forward with the push of a button. This allows the front seat to move to a location that will not interfere when the second row seat is stowed.

### NOTE:

The Stow 'n Go Assist feature is available to both the front driver and passenger power seats, if equipped.

For further information and applicable warnings and cautions, please refer to your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

## Power Adjustment (Rear Seats) – If Equipped

### Third Row Power Recline

The power recline feature, located on the trim panel next to the seat, adjusts the seatback angle forward/rearward for occupant comfort.

Push and hold the forward or rearward button, the seat will move in the direction of the button push. Release the button when the desired position is reached.

### Third Row Power Stow 'n Go Seat

A one-touch power folding seat switch is located in the right rear trim panel accessible from the cargo area as part of a switch bank. You can also adjust the 3rd row recline angle using the switch bank.



Rear Panel Power Switch Bank

- 1 – Open To Normal
- 2 – Stow
- 3 – Fold Forward/Rearward
- 4 – Right/Left Seats/Both Seats

For further information and applicable warnings and cautions, please refer to your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

## HANDS-FREE SLIDING DOORS/LIFTGATE

### Hands-Free Sliding Doors – If Equipped



Hands-Free Sliding Doors

To open the Hands-Free Sliding Doors, use a straight in and out kicking motion under the vehicle in the general location below the door handle(s). Do not move your foot sideways or in a sweeping motion or the sensors may not detect the motion.

When a valid kicking motion is completed, the sliding door will chime, the hazard lights will flash and the sliding door will open almost instantaneously. This assumes all options are enabled in the radio.

#### NOTE:

- To open the Hands-Free Sliding Doors requires a valid Passive Entry key fob within 5 ft (1.5 m) of the door handle. If a valid Passive Entry key fob is not within 5 ft (1.5 m), the door will not respond to any kicks.
- The Hands-Free Sliding Door will only operate when the transmission is in Park.
- If anything obstructs the Hands-Free Sliding Doors while opening, the sliding doors will automatically reverse to the closed position, provided it meets sufficient resistance.
- If a power sliding door encounters multiple obstructions within the same cycle, the system will automatically stop.
- The Hands-Free Sliding Doors feature may be turned on or off in Uconnect Settings. The Hands-Free Sliding Doors feature should be turned off during Jacking, Tire Changing, and Vehicle Service.

For further information and applicable warnings and cautions, please refer to your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

## Hands-Free Liftgate – If Equipped



Hands-Free Liftgate Activation Zone

To open the Hands-Free Liftgate, use a straight in and out kicking motion under the vehicle activation zone in the general location below the liftgate door handle. Do not move your foot sideways or in a sweeping motion or the sensors may not detect the motion.

#### Vehicles Equipped With A Trailer Tow Package

If your vehicle is equipped with the Trailer Tow Package, the hands-free activation zone(s) for the Power Liftgate will be located on the left and right side of the receiver. Use a straight kicking motion under either activation zone to open the Hands-Free Liftgate.



Hands-Free Liftgate Trailer Tow Activation Zones

When a valid kicking motion is completed, the liftgate will chime, the hazard lights will flash and the liftgate will open after approximately 1 second. This assumes all options are enabled in the radio.

**NOTE:**

- To open the Hands-Free Liftgate requires a valid Passive Entry key fob within 5 ft (1.5 m) of the door handle. If a valid Passive Entry key fob is not within 5 ft (1.5 m), the liftgate will not respond to any kicks.
- The Hands-Free Liftgate feature may be turned on or off in Uconnect Settings. The Hands-Free Liftgate feature should be turned off during Jacking, Tire Changing, and Vehicle Service.

**NOTE:**

- The Hands-Free Liftgate will only operate when the transmission is in Park.

- If anything obstructs the Hands-Free Liftgate while it is opening, the liftgate will automatically reverse to the closed position, provided it meets sufficient resistance.
- There are pinch sensors attached to the side of the liftgate opening. Light pressure anywhere along these strips will cause the liftgate to return to the open position.
- If the power liftgate encounters multiple obstructions within the same cycle, the system will automatically stop. If this occurs, the liftgate must be operated manually.
- The power liftgate will release, but not power open, in temperatures below -12° F (-24° C). Be sure to remove any buildup of snow or ice from the liftgate before opening the liftgate.
- If the liftgate is left open for an extended period of time, the liftgate may need to be closed manually to reset power liftgate functionality.

Gas props support the liftgate in the open position. However, because the gas pressure drops with temperature, it may be necessary to assist the props when opening the liftgate in cold weather.

**NOTE:**

Allow the power system to open the liftgate. Manually pushing or pulling the liftgate may activate the liftgate obstacle detection feature and stop the power operation or reverse its direction.

For further information and applicable warnings and cautions, please refer to your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).


## UTILITY FEATURES

### Stow 'n Vac Integrated Vacuum – If Equipped

Your vehicle may be equipped with an integrated vacuum system. This vacuum is for in-vehicle use only and should only be used on dry materials and on in-vehicle surfaces. It is located in the rear trim panel behind the sliding door on the driver's side of the vehicle.

#### NOTE:

Read all vacuum instructions, located in the lower access panel, before using. When using your vacuum, basic precautions should be followed.



Vacuum System Access Panels

- 1 – Upper Access Panel
- 2 – Lower Access Panel

For further information and applicable warnings and cautions, please refer to your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

## STARTING AND OPERATING

### Electric Park Brake (EPB)

Your vehicle is equipped with an Electric Park Brake (EPB) system that offers simple operation and some additional features that make the park brake more convenient and useful.



Electric Park Brake Switch

The park brake switch is located in the integrated center stack.

To engage the park brake manually, push the Electric Park Brake Switch.

To disengage the park brake manually, the ignition switch must be in the ON/RUN position. Press the brake pedal, then push the park brake switch down momentarily.

The park brake will disengage automatically when the ignition is in the ON/RUN position, the transmission is in DRIVE or REVERSE, the driver's seat belt is buckled, and an attempt is made to drive away by pressing the accelerator pedal.

The new Auto Park Brake feature can be used to apply the park brake automatically every time you park the vehicle. Auto Park Brake can be enabled and disabled in the Settings menu in Uconnect.

SafeHold is a new feature that will automatically apply the park brake under certain conditions. The EPB monitors the status of the driver's seat belt, driver's door, and pedal positions to determine if the driver may have exited while the vehicle is still capable of moving and will then automatically apply the park brake to prevent the vehicle from rolling.

**NOTE:**

- You may hear a slight whirring sound from the back of the vehicle while the park brake engages or disengages.
- Once the park brake is fully engaged, the BRAKE warning lamp in the instrument cluster and the LED indicator on the switch will illuminate. Once the park brake is fully disengaged, the BRAKE warning lamp in the instrument cluster and the LED indicator on the switch will extinguish.
- If your foot is on the brake pedal while you are engaging or disengaging the park brake, you may notice a small amount of brake pedal movement.
- The park brake can be engaged even when the ignition switch is OFF; however, it can only be disengaged when the ignition switch is in the ON/RUN position.

- The EPB fault lamp will illuminate if the EPB switch is held for longer than 20 seconds in either the released or applied position. The light will extinguish upon releasing the switch.
- Refer to “Electric Park Brake” in the “Starting And Operating” section in your Owner's Manual located at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals) for further details.

For further information and applicable warnings and cautions, please refer to your Owner's Manual located at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

## Engine STOP/START System (ESS) – If Equipped

The STOP/START system was developed to reduce emissions and will turn back ON every time the ignition is turned OFF and then back ON again. The system defaults back ON at every ignition cycle.



STOP/START Off Switch

The system will stop the engine automatically during a vehicle stop if the required conditions are met.

Releasing the brake pedal, pressing the accelerator pedal, or shifting out of DRIVE (D) will start the engine.


### How do I manually turn off/on the engine STOP/START system?

- Press the STOP/START OFF switch (located on the instrument panel). The light on the switch will illuminate when the system is off. The light on the switch will turn off when system is on.

### What are possible reasons the engine does not autostop?

- The hood is ajar.
- Driver's door is open.
- Driver's seat belt is unbuckled.
- The transmission is not in a forward gear.
- Cabin heating or cooling is in process and an acceptable cabin temperature has not been achieved.
- The vehicle has not reached a speed of 5 mph (8 km/h) after the previous autostop.

- Many of these reasons are displayed as a STOP/START message in the instrument cluster display on the STOP/START screen. The system must be in the "STOP/ START READY" state to autostop. To access the STOP/START section of the instrument cluster display, use the display controls. Refer to the "Starting and Operating" section of your Owner's Manual at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals) for a complete list of possible events in which the engine does not autostop.



STOP/START Message

# VEHICLE USER GUIDE – IF EQUIPPED

## Vehicle User Guide

Access your Owner's Information right through your Uconnect 8.4 or 8.4 NAV touchscreen system – If Equipped.

To access the Vehicle User Guide on your Uconnect Touchscreen: Press the Uconnect **Apps** button, then press the **Vehicle User Guide** icon on your touchscreen. No Uconnect registration is required.

### NOTE:

Vehicle User Guide features are not available while the vehicle is moving. If you try to access while the vehicle is in motion, the system will display: Feature not available while the vehicle is in motion.

### Pre-Installed Features

Your User Guide – Updated in real-time	Available when and where you need it
Touchscreen convenience	Customizable interface
Maintenance schedules and information	Multilingual
Comprehensive icon & symbol glossary	

# LIGHTS

## Automatic High Beam – If Equipped

This system automatically controls the operation of the headlamp high beams as oncoming vehicles approach.

- The Automatic High Beam Headlamp Control can be turned on or off using the Uconnect System.
- Push the turn signal lever away from you.
- With the headlight switch in the “AUTO” position, the high beams are controlled automatically.
- Pull the turn signal lever toward you to manually deactivate the system.
- To improve system recognition of crossing traffic and to limit use in a residential area, the vehicle must be moving at a speed greater than 20 mph (32 km/h) before the Automatic High Beam Module (AHBM) begins requesting high beam activation.

### NOTE:

If the windshield or Automatic High Beam Headlamp Control mirror is replaced, the mirror must be reaimed to ensure proper performance. See your local authorized dealer.

### How do I know I am in an autostop?

- The engine will shut down, the tachometer will move to the zero position and the STOP/START telltale will illuminate in the instrument cluster.

### How do I start the engine while in an autostop?

- While in a forward gear, the engine will start when the brake pedal is released or the throttle pedal is depressed. The transmission will automatically re-engage upon engine restart.

# UCONNECT ACCESS



Vehicle User Guide Home Screen

# UCONNECT ACCESS

## Registration

To activate your Uconnect Access Account:

1. Push the ASSIST button on your rearview mirror or in the Apps screen in the Uconnect System.



ASSIST Button

2. Select Uconnect Care on your Uconnect touch-screen.
3. A Uconnect Care agent will register your vehicle and handle all of the details.

Download the Uconnect Access app from the Apple App Store or from the Google Play Store to get the most out of your connected car experience. To use the app:

1. Download the Uconnect Access App onto your compatible smartphone.
2. Log in to the app using the email and password you provided when signing up for Uconnect Access.
3. Once you're logged in and have accepted the terms and conditions, you'll be able to start your vehicle and lock/unlock its doors from virtually anywhere!

## Services

### In-Vehicle Services

Use Uconnect Access for a range of added services including:

- Place a call to a local 9-1-1 Operator for emergency assistance.
- Turn your vehicle into a 3G Wi-Fi Hotspot and connect your devices to the internet.
- Listen to your text messages or send free-form text messages with your voice while keeping your hands on the wheel, using the Voice Texting feature. Requires a device that supports Bluetooth Message Access Profile (MAP).
- Search for places to eat, shop, relax and play with Yelp, using your voice or on-screen menu. Then navigate to them (navigation standard on Uconnect 8.4 NAV, optional on Uconnect 8.4).
- Get assistance from a Care representative using the ASSIST button on your interior rearview mirror.

## Remote Services

The Uconnect Access Mobile App helps you activate features from a distance. The remote features are:

- Lock/Unlock your doors from virtually anywhere.
- Start your car remotely.
- Sound the horn and flash the lights to help you find your car.
- Use Vehicle Finder to find where you parked.
- Use Send 'n Go to search for destinations on your phone and send the address directly to your Uconnect Navigation.
- Place a Uconnect Care call for customer assistance.

## Additional Services

- Receive monthly Vehicle Health Reports, and Alerts whenever a problem is detected.
- Receive stolen vehicle assistance, using GPS technology to help authorities locate your vehicle if it is stolen.
- Receive text or email notifications if your vehicle's security alarm goes off.

For further information on Uconnect Access, refer to your Uconnect Owner's Manual Supplement at [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals).

## Vehicle Finder And Send 'N Go


Two of the most convenient features of the Uconnect Access mobile app are Vehicle Finder and Send 'n Go.

### Vehicle Finder

Forget where you parked your car? Simply use the Uconnect Access app on your smartphone and you'll be on track. You can also sound the alarm and flash the lights to make finding your vehicle even easier. To find your vehicle:


1. Press the **Location** tab on the Uconnect Access mobile app.

2. Select the **Vehicle** icon to determine the location of your vehicle.



Vehicle Icon

3. Select the location of the vehicle, and then the arrow appears. Press the **Find Route** button that appears, once your vehicle is located.




Find Route Button

4. Select your preferred navigation app to route a path to your vehicle.

### Send 'n Go

Search for a destination on your mobile device and then send the route to your Uconnect Navigation system. To send a route to your vehicle:

1. Press the **Location** tab on the Uconnect Access mobile app.
2. Either type in the destination you would like to navigate to, or search through one of the categories provided.



Destination Search Bar

3. Select the destination you want to route to from the list that appears.
4. Press the **Send To Vehicle** button, and then confirm the destination by pressing “Yes,” to send the navigation route to the Uconnect Navigation in your vehicle.




Send To Vehicle Button

5. Finally, confirm the route inside your vehicle by pressing the “Go Now” option on the pop-up that appears on your Uconnect Touchscreen, when the vehicle is started.

# CHRYSLER VEHICLE OWNER'S MOBILE APP

## Key Features

- Owner Information For Your Vehicle
- Accident Assistant
- Parking Reminder
- Dealer Locator
- Brand Heritage
- Parts, Accessories, and Gear Store



To get this FREE application, go directly to the App Store or Google Play Store and enter the search keyword "Chrysler".



The Chrysler Vehicle Owner's Information Application is the essential app for owners of Chrysler brand vehicles. The app puts driver and lifestyle information right in the palm of your hand, anywhere you go.

Whether it's providing information about specific product features, taking a tour through your vehicle's heritage, knowing what steps to take following an accident, or scheduling your next appointment, we know you'll find the app an important extension of your Chrysler vehicle. Simply download the FREE app, select your make and model and enjoy the ride.



## Features/Benefits

- Available for free on iOS and Android smartphones and tablets.
- Select Chrysler brand vehicles from model year 2011 to current model year.
- You can also add other Jeep, Dodge, Ram, FIAT, or Alfa Romeo vehicles.\*
- Easy access to vehicle information anywhere you go using categories, bookmarks, search and an A-Z index.
- Vehicle information such as operating instructions, maintenance, service history, vehicle controls and emergency procedures.
- Find a dealer or an FCA-certified repair facility.
- Easily document and email an accident report.
- A parking reminder that allows you to drop a pin on your location and navigate back to your vehicle.
- Contact customer care with one click.
- Access to vehicle heritage, parts, accessories, and social media networks.
- Schedule your next service appointment.
- Available in English and Spanish.

\*App supports selected vehicles from model year 2011 to present.

To get this FREE application, go directly to the App Store or Google Play Store and enter the search keyword "Chrysler".





Whether it's providing information about specific product features, taking a tour through your vehicle's heritage, knowing what steps to take following an accident, or scheduling your next appointment, we know you'll find the app an important extension of your Chrysler vehicle. Simply download the **app**, select your make and model and enjoy the ride. To get this **app**, go directly to the App Store or Google Play and enter the search keyword "**Chrysler**".

**Chrysler.com/EN/Owners** provides special offers tailored to your needs, customized vehicle galleries, personalized service records and more. To get this information, just create an account and check back often.

Download a **FREE electronic copy** of the Owner's Manual or Warranty Booklet by visiting:

**[www.mopar.com/chrysler](http://www.mopar.com/chrysler), [www.chrysler.com/en/owners/manuals](http://www.chrysler.com/en/owners/manuals) or**

**[www.chrysler.com/en/warranty](http://www.chrysler.com/en/warranty) (U.S.);**

**[www.owners.mopar.ca/en](http://www.owners.mopar.ca/en) (Canada).**

---

**[chrysler.com/pacifica](http://chrysler.com/pacifica) (U.S.)**

**[chrysler.ca/pacifica](http://chrysler.ca/pacifica) (Canada)**

©2017 FCA US LLC. All Rights Reserved. Chrysler is a registered trademark of FCA US LLC.



RU-QRG-AA • PACIFICA  
THIRD EDITION • QUICK REFERENCE GUIDE